



characteristic

Filtered and lubricated air





G 1/4"

mm 8

Max.

+50°C

1100 NI/min

Min.

-5°C

10 bar



Solenoid - Differential Solenoid - Spring 4/2 5/2 Ordering code T514.t .00.f .v TYPF 42 = 4 ways 52 = 5 ways FUNCTION 36 = Solenoid - Differential 39 = Solenoid - Spring VOLTAGE B04 = 12 VDC B05 = 24 VDC B09 = 24 VDC (2W) B56 = 24V (50-60 Hz) B57 = 110V (50-60 Hz) B58 = 220V (50-60 Hz) Weight gr. 200 Minimum pilot pressure 2,5 bar Maximum fixing torque for fittings 9 N/m 14

Max working pressure Flow rate at 6 bar with Temperature °C Fluid Orifice size (mm) Working ports size Operational (bar) $\Delta p = 1$ (NI/min) characteristic Min. Max. Filtered and lubricated air 10 bar 1100 NI/min mm 8 G 1/4" -5°C +50°C


Universal kit

Ordering code

T514.92.00.f .v

f	FUNCTION				
	16 = Pneumatic - Differential				
	18 = Pneumatic - Pneumatic				
	19 = Pneumatic - Spring				
	35 = Solenoid - Solenoid				
	36 = Solenoid - Differential				
	39 = Solenoid - Spring				
v	VOLTAGE				
	B04 = 12 VDC				
	B05 = 24 VDC				
	B09 = 24 VDC (2W)				
	B56 = 24V (50-60 Hz)				
	B57 = 110V (50-60 Hz)				
	B58 = 220V (50-60 Hz)				





Weight gr. 170 Minimum pilot pressure 2,5 bar Maximum fixing torque for fittings 9 N/m





To change a 5/2 valve into a 4/2: Simply replace the bottom plate with the one included in the universal kit (cod. T514.92....) and by plugging port 5

Operational characteristic	Fluid	Max working pressure (bar)	Temperature °C	Flow rate at 6 bar with Δp=1 (NI/min)	Orifice size (mm)	Working ports size
	Filtered and lubricated air	10 bar	Min. Max. -5°C +50°C	1100 NI/min	mm 8	G 1/4"